31/08/2001

ENGINE



M0020100

- XU INJECTION

A) IF NECESSARY GET BACK OR CHANGE OIL HOUSING
B) GET BACK OR CHANGE THE OIL PUMP ANTIGAUGING PANEL + OIL PUMP
C) IF NECESSARY CHANGE LOWER RIGHT BRACKET
D) FOR "ME" OR AUTOMATIC GEARBOX, CHANGE OR GET BACK THE RIGHT INTERMEDIATE ENGINE BRACKET

1	**0135 Y7**	01	**NEW ENGINE** REPERE **RGX - RGY** -TURBO INJECTION XU10J2TE **SEE A B TO O 06747**
			EXCHANGE ENGINE
	0139 P4	01	REPERE (RGX) - **RGX - RGY** -TURBO INJECTION XU10J2TE SEE A B TO O 06747
	0139 W0	01	REPERE **RGX** -TURBO INJECTION XU10J2TE SEE A,B FROM O 06748 TO O 08133
	0135 0V	01	**NEW ENGINE** REPERE **RGX** -TURBO INJECTION XU10J2TE SEE A,B FROM O 06748
	0139 KW	01	**EXCHANGE ENGINE** REPERE **RGX** -TURBO INJECTION XU10J2TE SEE A,B
	0135 3Q	01	**NEW ENGINE** REPERE **RFV** -INJECTION XU10J4R SEE A B TO O 06844 OR BVM BE3 FROM O 06845 TO O 07083 OR BVM ME FROM O 06945 TO O 07664 OR BVA SEE A,B,D (+ 5970 73 + 1565 P5) FROM O 06945 TO O 07664
			EXCHANGE ENGINE
	0139 Q8	01	REPERE (RFV) - **RFV** -INJECTION XU10J4R SEE A,B TO O 06944
	0139 Y3	01	REPERE (RFV) - **RFV** -INJECTION XU10J4R GEARBOX BE3 FROM O 06945 TO O 07083 OR BVM ME FROM O 06945 TO O 07664

.../...



06/94 M0020100

M0020100

1	.../...	**0139 Y3**	01 **EXCHANGE ENGINE** OR BVA SEE A,B,D FROM O 08815 TO O 07684
		0139 T7	01 REPERE RFV -INJECTION XU10J4R, GEARBOX BE3 FROM O 07084 TO O 07684
		0135 1Q	01 **NEW ENGINE** REPERE RFV -INJECTION XU10J4R: GEARBOX BE3 (+ 5970 73 + 1565 P5 FROM O 07084 TO O 07684) FROM O 07685 TO O 07972 OR GEARBOX BE3R FROM O 07973
		0139 FX	01 **EXCHANGE ENGINE** REPERE RFV -INJECTION XU10J4R: GEARBOX BE3 FROM O 07685 TO O 07972 OR GEARBOX BE3R FROM O 07973
		0139 FZ	01 REPERE RFV -INJECTION XU10J4R: BVM ME OR BVA
51		**0135 .5**	01 **NEW ENGINE** REPERE (R6A) - R6A -INJECTION XU10J2 SEE A C

31/08/2001

ENGINE



[10/96] M0020200

M0020200

- INJECTION ZPJ OR INJECTION ZPJ4

A) FOR COOLING, GET BACK OR CHANGE THE 9804402R EXCHANGER
B) + FOR 98051190 (1) AUTOMATIC GEARBOX OR 98024813 (1) MECANICAL GEARBOX

1	0135 Y2	01	**NEW ENGINE** REPERE UFY - UFZ -INJECTION ZPJ SEE A) & B)
	0139 N0	01	**EXCHANGE ENGINE** REPERE UFZ -INJECTION ZPJ SEE A,B (REP UFY)
	0135 Y4	01	**NEW ENGINE** REPERE UKZ -INJECTION ZPJ4 SEE B)
	0139 P1	01	**EXCHANGE ENGINE** REPERE UKZ -INJECTION ZPJ4 SEE B

31/08/2001

ENGINE

- INJECTION ES9J4



1	0135 4N	01	**NEW ENGINE** REPERE AFZ

31/08/2001

ENGINE

- DIESEL XUD11A
- TO O 07C83

NOTE : ENGINE IS PROVIDED WITHOUT STEERING WHEEL, CLUTCH, EXHAUST MANIFOLD, INJECTION SYSTEM, TURNING ENGINE. FOR AIR CONDITIONING MOTOR GET BACK THE ALUMINIUM HOUSING ON THE EXCHANGE MOTOR



M0020700

1	0135 K2	01	**NEW ENGINE** REPERE (PJZ) - **PJZ - P8A**
	0139 C3	01	**EXCHANGE ENGINE** REPERE **PJZ - P8A**

M0020700



M0020710

- TURBO DIESEL XUD11ATE OR TURBO DIESEL XUD11BTE

NOTE : FOR COOLING, GET BACK THE OIL HOUSING - FOR AUTOMATIC GEARBOX, ASSEMBLE THE 1338 72 THERMOSTAT

1	95 668 062	01	**NEW ENGINE** REPERE **P8B** -TURBO DIESEL XUD11ATE, EEC 19-5 DEPOLL (ENGINE) TO O 06778
	0139 HS	01	**EXCHANGE ENGINE** REPERE **P8B** -TURBO DIESEL XUD11ATE, EEC 19-5 DEPOLL (ENGINE) TO O 06778
	95 655 251	01	**NEW ENGINE** REPERE **PHZ** -TURBO DIESEL XUD11ATE, US 87 DEPOLL (ENGINE) TO O 06778
	0139 H7	01	**EXCHANGE ENGINE** REPERE **PHZ** -TURBO DIESEL XUD11ATE, US 87 DEPOLL (ENGINE) TO O 06778
	0135 9F	01	**NEW ENGINE** REPERE **PHZ - P8B** -TURBO DIESEL XUD11ATE FROM O 06779 TO O 07237
	0139 HL	01	**EXCHANGE ENGINE** -TURBO DIESEL XUD11ATE REF (PHZ) - P8B FROM O 06779 TO O 07237
	0135 0C	01	**NEW ENGINE** REPERE **P8C** -TURBO DIESEL XUD11BTE TO O 06778
	0139 HK	01	**EXCHANGE ENGINE** REPERE **P8C** -TURBO DIESEL XUD11BTE REF P8C TO O 06778
	0135 4L	01	**NEW ENGINE** REPERE **P8C** -TURBO DIESEL XUD11BTE: WITHOUT AIR CONDITIONING FROM O 06779 OR AIR CONDITIONING FROM O 06779 TO O 07314 OR EEC 19-5 DEPOLL (ENGINE), SINGLE AIR CONDITIONING SEE NOTA FROM O 07315 OR EEC 95 DEPOLL (ENGINE), SINGLE AIR CONDITIONING FROM O 07315

.../...



08/94 M0020710

M0020710

0139 HP	01	**EXCHANGE ENGINE** REPERE P8C -TURBO DIESEL XUD11BTE. WITHOUT AIR CONDITIONING FROM O 06779 OR SINGLE AIR CONDITIONING FROM O 06779 TO O 07314 OR EEC 19-5 DEPOLL (ENGINE), SINGLE AIR CONDITIONING SEE NOTA FROM O 07315 OR EEC 95 DEPOLL (ENGINE), SINGLE AIR CONDITIONING REP P8C FROM O 07315
0135 6L	01	**NEW ENGINE** REPERE P8C - 10DA5Q - 10DA5R 10DA6Q - 10DA6R -TURBO DIESEL XUD11BTE. EEC 2000 DEPOLL (ENGINE) SEE NOTA FROM O 07756
0139 EE	01	**EXCHANGE ENGINE** REPERE P8C - 10DA5Q - 10DA5R 10DA6Q - 10DA6R

31/08/2001

ENGINE



08/04

M0020850

M0020850

- TURBO DIESEL DK5ATE

1	**0135 0P**	01	**NEW ENGINE** REPERE THY - EEC 19-5 DEPOLL (ENGINE) + 0235 13 (01) + 0235 14 (01) TO O 06778 OR EEC 95 DEPOLL (ENGINE) (+ 0235 13 (01) + 0235 14 (01) TO O 7601) OR US 87 DEPOLL (ENGINE) + 0235 13 (01) + 0235 14 (01) TO O 07205
	0139 AK **RP 0139 AJ**	01 01	*EXCHANGE ENGINE* *EMISSION CEE 19-5 (ENGINE) TO O 7205* *- EEC 95 DEPOLL (ENGINE)* *OR US 87 DEPOLL (ENGINE)*